

Mini Squirt® Hot Melt Adhesive Applicator



Portable adhesive dispensing system delivers efficient hot melt adhesive application.



The compact, handheld Mini Squirt hot melt adhesive applicator provides reliable bonding for small, simple applications. The portable design makes it easy to handle and the wire stand provides freestanding support on convenient work surfaces. The Mini Squirt applicator's clean, quiet operation is ideal for office and light industrial environments.

The Mini Squirt adhesive applicator is easy to operate. Plug-in the all-electric unit and fill the tank with hot melt adhesive. The applicator is ready for use after a 10 to 15 minute warm-up.

The tank reservoir holds up to 7 ounces of adhesive in a variety of forms: granule, chicklet or pillow.

- **Lightweight, portable design** for use in office and light industrial environments.
- **Tank reservoir** accommodates various adhesive forms.
- **Trigger-activated piston plunger** assures smooth operation.
- **A variety of dispensing nozzles** is available to meet specific requirements

Mini Squirt® Hot Melt Adhesive Applicator



Holds variety of adhesive forms.



Adjustable thermostat controls.

Specifications

Tank Capacity

Dry	4 oz (113 g)
Fluid	7 oz (198 g)

Warm-up Time (max.) 15 minutes

Dispense Rate 4 oz/min (0.12 l/min)

Temperature Range Adjustable up to 375° F (190° C)

Electrical 110/115 V, 2A max
230 V, 1A max

Weight 2.6 lb (1.18 kg)

Nozzles

Extended Single Orifice (diameter)	0.070 in (1.8 mm)
Single Orifice (diameter)	0.040, 0.070 or 0.100 in (1.0, 1.8 or 2.5 mm)
Slot Swivel (slot width)	0.300 or 0.700 in (7.6 or 17.8 mm)

Nozzle kit includes one (1) each of single orifice and slot swivel nozzle.

For more information, talk with your Nordson representative or contact your Nordson regional office.

United States

Duluth, Georgia
Telephone: (800) 683-2314
Toll-free Facsimile:
(866) 667-3329

Canada

Markham, Ontario
Telephone: (800) 463-3200
Facsimile: (905) 475-8821

Europe

Lüneburg, Germany
Telephone: (49) 4131-894-0
Facsimile: (49) 4131-894-149

Japan

Tokyo, Japan
Telephone: (81) 3-5762-2700
Facsimile: (81) 3-5762-2701

Asia/Australia/ Latin America

Amherst, Ohio
Telephone: (440) 985-4797
Facsimile: (440) 985-1096

www.nordson.com



When you expect more.®